



922-111

**Communication Server 1000 to RIs. 6.0 Upgrades for
Technicians**

Q&A

DEMO Version

Important Note Please Read Carefully

For demonstration purpose only, this free version Chinatag study guide contains **10** full length questions selected from our full version products which have more than **200** questions each.

This Study guide has been carefully written and compiled by Chinatag certification experts. It is designed to help you learn the concepts behind the questions rather than be a strict memorization tool. Repeated readings will increase your comprehension.

For promotion purposes, all PDF files are **not** encrypted. Feel free to distribute copies among your friends and let them know Chinatag website.

Study Tips

This product will provide you questions and answers along with detailed explanations carefully compiled and written by our experts. Try to understand the concepts behind the questions instead of cramming the questions. Go through the entire document at least twice so that you make sure that you are not missing anything.

Latest Version

We are constantly reviewing our products. New material is added and old material is revised. Free updates are available for 90 days after the purchase. You should check the products page on the <http://www.chinatag.com> website for an update 3-4 days before the scheduled exam date.

Please tell us what you think of our products. We appreciate both positive and critical comments as your feedback helps us improve future versions. Feedback on specific questions should be send to feedback@chinatag.com.

Thanks for purchasing our products and look forward to supplying you with all your Certification training needs.

Good studying!

Technical and Support Team
Chinatag LLC.

Question: 1

A customer with a Communication Server (CS) 1000E RIs. 5.5 HA system with two IPMGs and dual CPPM Signaling Servers is upgrading their system to release 6.0. The system is part of an IP Peer Network that includes a NRS database. Which upgrade step is correct?

- A. Use NRS Manager to download the NRS backup file to a compact flash.
- B. Use Element Manager to download the Signaling Server backup file to a compact.
- C. User NRS Manager to download the NRS backup file to the local PC.
- D. Use Element Manager to download the Signaling Server backup file to the local PC.

Answer: C

Question: 2

A customer with an existing Option 11C RIs. 5.5 chassis system is planning to upgrade to a Communication Server 1000E RIs. 6.0 Standard Availability. A CPPM Co-Resident Call Server and Signaling Server card will be installed. The system will automatically map small system Terminal Numbers to large system Terminal format during the upgrade. In this upgrade scenario, which actions must be completed manually? (Choose two.)

- A. Re-programming Digital Trunk Terminal Numbers with a new format.
- B. Programming the DSP daughterboards on the IP Media Gateway.
- C. Entering the IP address for each IP Media Gateway in LD 97.
- D. Re-programming Tone Receiver Terminal Numbers with a new format.

Answer: B, C

Question: 3

A customer with an existing Option 11C RIs. 5.5 chassis system is planning to upgrade to a Communication Server 1000E RIs. 6.0 Standard Availability. A CPPM card will be installed as a Co-Resident Call Server and Signaling Server during the upgrade. Which task must be completed prior to loading Linux Base onto the card? (Choose two.)

- A. The BIOS of the card must be updated to version 18.
- B. The S5 switch must be set to position 1.
- C. The CMOS settings must be reset to factory defaults.
- D. The on-board 1 GB Compact Flash must be installed.

Answer: A, C

Question: 4

Click on the Exhibit button.

You are upgrading a single site Option 11C RIs. 5.5 system to a Communication Server 1000E RIs. 6.0 Standard Availability with a single IP Media Gateway (MG) 1000E chassis. The customer is using a CPPM card from inventory as a CPPM Co-Resident Call Server and Signaling Server. Based on the output received when the card boots up, shown in the exhibit, what must done before Linux Base can be loaded?

- B. The CPPM Co-Resident Call Server and Signaling Server can also support the SIP Line Gateway application.
- C. The CPPM Co-Resident Call Server and Signaling Server support the use of a USB memory device to install Linux Base software.
- D. The CPPM Co-Resident Call Server and Signaling Server support the use of a USB memory device to install Nortel applications.

Answer: A, D

Question: 7

A customer with an existing Option 11C Rls. 5.5 chassis system plans to upgrade to a Communication Server (CS) 1000E Rls. 6.0 Standard Availability with a single IP Media Gateway (MG) 1000E chassis. Which component must be replaced in the Option 11C to complete the upgrade?

- A. SSC Card
- B. Call Processor
- C. Media Gateway
- D. Digital Line Card

Answer: A

Question: 8

A customer is upgrading an existing Option 11C Rls. 5.5 chassis system to a Communication Server 1000E Rls. 6.0 Standard Availability with a single IP Media Gateway 1000E chassis. As part of this upgrade a CPPM Call Co-Resident Call Server and Signaling Server Card has been added. What happens to the Terminal Number (TN) format during this upgrade?

- A. The TN format is automatically converted to the large system format of Loop-Shelf-Card-Unit for all assigned Terminal Numbers.
- B. The TN format is automatically converted to the large system format of Card-Unit for all assigned Terminal Numbers.
- C. The TN format will be automatically converted to the large system format of Loop-Shelf-Card-Unit for all new programmed Terminal Numbers.
- D. The format is automatically converted to the large system format of Loop-Shelf-Card-Unit for IP Phones only. All other devices assigned Terminal Numbers must be manually reprogrammed.

Answer: A

Question: 9

A customer is upgrading a single site Option 11C Rls. 5.5 system to a Communication Server 1000E Rls. 6.0 system with a single IP Media Gateway (MG) 1000E chassis. The Linux Base has been successfully loaded onto the CPPM Co-Resident card. From a browser, what is the next step in the upgrade process?

- A. Enter the FQDN of the server and log into Deployment Manager to deploy applications.
- B. Enter the FQDN of the server and log into Base Manager to complete the Security Configuration.
- C. Enter the ELAN IP address of the server and log into Deployment Manager to deploy applications.
- D. Enter the ELAN IP address of the server and log in to Base Manager to complete the Security Configuration.

Answer: B

Question: 10

A customer is upgrading an existing Option 11C RIs. 5.5 chassis system to a Communication Server (CS) 1000E RIs. 6.0 Standard Availability with a CPPM Co-Resident Call Server and Signaling Server card to be installed during the upgrade. Which two statements correctly describe the software installation process? (Choose two.)

- A. Before installing Linux Base software, the server must be configured as a primary, secondary or member server.
- B. Nortel applications software is loaded onto the server using the CS 1000 Software Deployment Manager.
- C. Linux Base software is installed using command line interface and a bootable Compact Flash containing software and operating system.
- D. Linux Base software and Nortel application software are pre-loaded onto the CPPM card at the factory.

Answer: B, C